

Torque Conversion Table

Screwdrivers and Nutsetters

Torque Conversion Table

in.-lbs	ft.-lbs	Nm	in.-lbs	ft.-lbs	Nm	in.-lbs	ft.-lbs	Nm	in.-lbs	ft.-lbs	Nm
1	.08	.11	27	2.25	3.05	54	4.50	6.10	80	6.66	9.04
2	.17	.23	28	2.33	3.16	55	4.58	6.21	81	6.75	9.15
3	.25	.34	29	2.42	3.28	56	4.68	6.33	82	6.83	9.27
4	.33	.45	30	2.50	3.39	57	4.75	6.44	83	6.92	9.38
5	.42	.57	31	2.58	3.50	58	4.83	6.55	84	7.00	9.49
6	.50	.68	32	2.67	3.62	59	4.92	6.67	85	7.08	9.61
7	.58	.80	33	2.75	3.73	60	5.00	6.78	86	7.16	9.72
8	.66	.90	34	2.83	3.84	61	5.08	6.89	87	7.25	9.83
9	.75	1.02	36	3.00	4.07	62	5.16	7.01	88	7.33	9.94
10	.83	1.13	37	3.08	4.18	63	5.25	7.12	89	7.42	10.06
11	.92	1.24	38	3.16	4.29	64	5.33	7.23	90	7.50	10.17
12	1.00	1.35	39	3.25	4.41	65	5.42	7.35	91	7.58	10.28
13	1.08	1.47	40	3.33	4.52	66	5.50	7.46	92	7.66	10.40
14	1.16	1.58	41	3.42	4.63	67	5.58	7.57	93	7.75	10.51
15	1.25	1.70	42	3.50	4.75	68	5.66	7.68	94	7.83	10.62
16	1.33	1.81	43	3.58	4.86	69	5.75	7.80	95	7.92	10.74
17	1.42	1.92	44	3.66	4.97	70	5.83	7.91	96	8.00	10.85
18	1.50	2.03	45	3.75	5.09	71	5.92	8.02	97	8.08	10.96
19	1.58	2.15	46	3.83	5.20	72	6.00	8.14	98	8.16	11.07
20	1.66	2.26	47	3.92	5.31	73	6.08	8.25	99	8.25	11.19
21	1.75	2.37	48	4.00	5.42	74	6.14	8.36	100	8.33	11.30
22	1.83	2.49	49	4.08	5.54	75	6.25	8.48	108	9.00	12.20
23	1.92	2.60	50	4.16	5.65	76	6.33	8.59	120	10.00	13.50
24	2.00	2.71	51	4.25	5.76	77	6.42	8.70	132	11.00	14.90
25	2.08	2.83	52	4.33	5.88	78	6.50	8.81			
26	2.16	2.94	53	4.42	5.99	79	6.58	8.93			

Inch Pounds x 0.113 = Newton Meters
 Newton Meters x 8.849 = Inch Pounds
 Foot Pounds x 1.356 = Newton Meters
 Newton Meters x 0.737 = Foot Pounds

Model Identification Guide

Example: SA024C-26-Q

